

Description	Part number
Jaws (pair)	RP110-008
Nosepiece 1/8"	RP110-009
Nosepiece 5/32"	RP110-010
Nosepiece 3/16"	RP110-011

RiveDrill RT110

Operating Instructions

1. Choose correct nosepiece (1/8", 5/32" 3/16") for blind rivet size and thread on to end of knurled frame head (7).
2. Insert hex shaft in drill chuck and tighten.
3. Pull back on telescopic protective case until it stops.
4. If hole (B) is open, reverse tool direction until hole is covered by internal jaw.
5. Set tool in forward motion, insert rivet in nosepiece and place rivet in application. (C)
6. Hold telescopic, protective case in one hand and pull drill trigger with other to set the rivet. (D)
7. After rivet is set, place drill in reverse direction and pull trigger until rivet mandrel is ejected and clicking sounds is heard. This allows the jaws to return to riveting position. (E)
8. To rivet again, repeat steps 5-7



s-b industries

2275-147 Cassens Dr. • Fenton, MO 63026 • 800-543-1011 • 636-343-1487