


EXPLODE VIEW AR-021H



INDEX NO.	CODE NO.	PARTS NAME
01-A	10213	NOSE PIECE (M) 2.4 (3/32")
01-B	10214	NOSE PIECE (M) 3.2 (1/8")
01-C	10215	NOSE PIECE (M) 4.0 (5/32")
01-D	14350	NOSE PIECE (M) 4.8 (3/16")
01-F	10226	NOSE PIECE (H) 6.4 (1/4")
01	15169	SET OF 5 NOSE PIECES INCLUDES 01-A, 01-B, 01-C, 01-D & 01-F
02	10191	FRAME HEAD
03	14378	JAW CASE HEAD (M)
03-A	10447	JAW CASE HEAD (H)
04	10281	A PAIR OF ULTRA JAWS (M)
04-A	10493	A PAIR OF ULTRA JAWS (H)
05	10209	JAW PUSHER (M)
05-A	10224	JAW PUSHER (H)
06	10429	JAW CASE
07	10448	COLLAR FOR JAW CASE
08	10210	JAW PUSHER SPRING
09	10449	COLLAR SPRING
10	10148	LOCK WASHER
11	10113	JAW CASE LOCK NUT
12	10128	O-RING (P-12)
13	10129	BACK-UP RING (P-12)
14	14384	FRAME ONLY
15	12120	O-RING (P-5)
16	12135	BLEED PLUG
17	10195	OIL PISTON
18	10207	O-RING (P-24)
19	10208	BACK-UP RING (P-24)

INDEX NO.	CODE NO.	PARTS NAME
20A	10196	RETURN SPRING 'A' (INNER)
20B	10197	RETURN SPRING 'B' (OUTER)
20	14139	RETURN SPRING A+B (SET)
21	10221	O-RING (S-28)
22	10192	HANGER CLIP
23	10190	FRAME CAP
24	14051	SAFETY CAP
25	10194	SAFETY CAP NUT
26	13126	TRIGGER, LONG
27	10202	CONNECTOR
28	10119	TRIGGER LEVER
29	10147	SPRING PIN (3×6mm)
30	14415	AIR CYLINDER
31	10112	FRAME LOCK NUT
32	10144	SPRING PIN (3×22mm)
33	10145	SPRING PIN (3×18mm)
34	14154	SLOTTED PIN (4×31mm)
35	10219	O-RING (P-9)
36	14435	VALVE PUSHER
37	12120	O-RING (P-5)
38	10453	VALVE PUSHER SPRING
39	10274	O-RING (P-10)
40	10491	VALVE SLEEVE
41	12120	O-RING (P-5)
42	10247	VALVE (STEEL BALL 8.0φmm)
43	14575	VALVE SPRING
44	10152	O-RING (S-14)
45	10127	NIPPLE 3/8"-1/4"

PARTS LIST

INDEX NO.	CODE NO.	PARTS NAME
46	10212	O-RING (P-70)
47	14365	AIR PISTON UNIT (INCLUDES 48 BUMPER)
48	10114	BUMPER (RUBBER CUSHION)
49	10211	O-RING (G-80)
50	14427	AIR CYLINDER CAP
51	14355	SILENCER
52	14359	PLUG
80	15905	DECAL, CAUTION
81	12136	SPANNER 'A'
82	10218	SPANNER 'B'
83	10143	CLEANING BRUSH
84	10140	AIR HOSE JOINT 1/4"
85	10139	AIR HOSE JOINT NUT 1/4"
86	10012	HYDRAULIC OIL
87	14142	PRIMING PUMP

RECOMMENDED SPARES IN KITS

INDEX NO.	CODE NO.	PARTS NAMES
100	15173	AUXILIARY & ACCESSORY KIT (INCLUDES NOS.1, 3A, 4A, 5A, 81, 82, 83, 84, 85, 86, & 87.)
101	15177	TRIGGER ASSEMBLY (INCLUDES 26, 27, 28, 29-2PCS., 32, & 33.)
102	14372	AIR PISTON ASSEMBLY (INCLUDES 46, 47 & 48)
103	14151	OIL PISTON ASSEMBLY (INCLUDES 17, 18 & 19)
104	15181	FRAME ASSEMBLY (INCLUDES 14, 12-4PCS., 13-2PCS., 15 & 16.)
105	15185	HYDRAULIC SEAL KIT (INCLUDES 21, 12-4PCS., 13-2PCS., & 15.)
106	15189	PISTON SEAL KIT (INCLUDES 18, 19, 46, & 49.)
107	15193	VALVE SEAL KIT (INCLUDES 35, 37, 39, 41, & 44.)
108	15197	LIGHT SPRINGS & VALVE KIT (INCLUDES 8, 38, 43, & 42.)
109	15201	MAINTENANCE KIT (COMPLETE SET OF 105, 106, 107, & 108.)
110	14007	AUXILIARY TOOL KIT (INCLUDES 1A, 1B, 1C, 1F, 4A, 5A, 81, 82, 83, 84, & 85.)