

Parts for ER-300N

Index No.	Code No.	Parts Name
ER-01	10409	Frame Cap
ER-02A	10027	Nose Piece (S) 2.4 (3/32)
ER-02B	10028	Nose Piece (S) 3.2 (1/8)
ER-02C	10029	Nose Piece (S) 4.0 (5/32)
ER-02D	10030	Nose Piece (S) 4.8 (3/16)
ER-03	10457	Frame Head
ER-04	10547	Snap Ring
ER-05	10280	Jaw Case Head
ER-06	10281	Ultra Jaws (set) M
ER-07	10548	Jaw Pusher
ER-08	10552	Jaw Pusher Spring
ER-09	10558	Mandrel Pusher
ER-10	10567	Mandrel Pusher Spring
(ER-11)	10672	Front Flange
ER-12	10673	Stop Ring
ER-13	10679	Spindle (Pulling Head)
ER-14	10680	Connector Pin
ER-15	10887	Pan Head Screw (+) M4×10
ER-16	10681	Worm Cover
ER-17	10682	Worm Cover Packing
ER-18	10683	Connector Plate "L"
ER-19	10684	Worm Gear
ER-20	10685	Connector Plate "R"
ER-21	10686	Pan Head Screw (+) M5×30
ER-22	10687	Pan Head Screw (+) M5×50
ER-24	10694	SJT Cable
ER-25	10695	Trigger Switch
ER-27	12846	Insulated Connector
ER-28	12847	P-Screw with S/W (+) M4×6
ER-29	12848	Insulated Sleeve
ER-30	12849	Rubber Bush
ER-31	12851	Cord Clamp
ER-32	10508	Pan Head Screw (+) M4×8
ER-33	12853	Worm Pin
ER-34	12854	Gear Box
ER-35	12855	Needle Bearing
ER-36	12856	Thrust Bearing
ER-37	12857	Washer "A"
ER-38	12858	Worm Shaft
ER-39	12859	Key (Half Moon Type)
ER-40	12860	Ball Bearing
ER-41	12861	Gear, 4th
ER-42	12862	Washer "B"

Parts for ER-300N

Index No.	Code No.	Parts Name
(ER-43)	12863	Metal
ER-44	12864	Ball Bearing
(ER-45)	12865	Gear, 3rd
ER-46	12866	Gear, 2nd
ER-47	12862	Washer "B"
(ER-48)	12863	Metal
ER-49	12885	Grip Cover
ER-50	12867	P-Screw with S/W (+) M4 x 10
ER-51	12868	Housing
ER-52	12869	Fan Guide
ER-53	12870	Ball Bearing
ER-54	12871	Armature
ER-55	12872	P-Screw with S/W (+) M4 x 60
ER-56	12873	Stator
ER-57	12874	Ball Bearing
ER-58	12875	Motor Housing
ER-59	12876	Flow-Thru Venting
ER-60	12877	Pan Head Screw (+) M4 x 6
ER-61	12878	Name Plate
ER-62	12879	Brush Holder Cap
ER-63	12880	Carbon Brush
ER-64	12881	Brush Holder
ER-65	12882	P-Screw with S/W (+) M3 x 4
ER-67	12884	Set Screw
ER-68	10044	Spanner

() These are supplied assembled in major parts as follows:
 ER-11 is the integral part of ER-34 Gear Box.
 ER-43 & ER-48 are press fitted inside ER-51 Housing.
 ER-45 is supplied assembled on ER-46 Gear No: 2.