AR2000HV(A) PARTS TABLE



● For disassembly of dotted line area ( ) contact with your local dealer.



Index No.	Part name	Code No.	Index No.	Part name	Code No.
1－A	Nosepiece 'L' 4.8 (3/16)	10216	39	O-ring P-34	24311
1－B	Nosepiece 'H' 6.4 (1/4)	10226	43	Switch	29348
2	Frame head 'H'	29709	44	Valve sleeve	29350
③	Jaw case head 'H'	10447	45	Miniature straight	42510
④	Ultra jaws (pair) 'H'	10493	46	Polyurethane tube 125 mm	29729
⑤	Jaw case 'H'	10429	47	Frame cover 'HA-R'	44551
⑥	Jaw pusher 'H'	29710	48	Frame cover 'HA-L'	44552
⑦	Jaw pusher spring 'H'	29711	49	Pan head tapping screw 3×10	29340
8	Jaw case collar 'H'	10448	50	Flat head tapping screw 5×35	29367
9	Collar spring 'H'	10449	53*3	Cylinder top (with muffler)	43586
10－A	Guide pipe 'E' 4.8 (3/16)	41203	54	Muffler 'HA'	44567
10－B	Guide pipe 'F' 6.4 (1/4)	29752	55	Frame lock nut 'H'	29757
11	Lock washer	10148	56	Rubber cushion 'H'	29736
12	Jaw case lock nut 'H'	29712	57*4	Air piston unit 'H'	29758
13	Stop ring	23634	58	O-ring P-70	10212
14*1	Frame unit 'HA'	44703	59	Cylinder cup 'H'	29741
15	Bleed plug (Hexagon socket head cap screw)	29337	60	Grommet	29361
16	Pack seal 6 mm	10355	61	O-ring S-5	10276
17	Polyurethane tube 230 mm	29730	62	Cylinder cover 'H'	29740
18	Connector	29354	63	O-ring P-10	10274
19	O-ring P-12	10128	64	O-ring P-7	10149
20	B-ring P-12	10129	65	Change plug	29375
21	Oil piston 'Z'	41270	66	Pan head tapping screw 4×20	29610
22	O-ring P-24	10207	67	Cylinder bottom 'H'	29739
23	B-ring P-24	10208	69	Spool	29612
24	Back piston 'Z'	41216	70	O-ring P-5 (4D)	29613
25	O-ring S-7	12114	71	O-ring P-8 (4D)	29614
26	Nozzle unit (with O-ring)	41201	73	O-ring P-9	10219
27	Flange 'Z'	41214	74	"LOBSTER" brand hydraulic oil	10012
28	Return spring 'H'	29726	75	Spanner 'B'	29642
29	O-ring S-32	29727	76	Spanner 'A'	10217
30	Hanger clip	10192	78	Hex key wrench 5 mm	25777
31	Frame cap 'HV'	29690	79	Priming pump (syringe unit)	29624
31U	Frame cap unit 'HV'	29831	80	Cross recessed head screw 6×10	20916
32	Air valve 'H' (with O-rings)	29832	81	Rotary joint	42501
33	O-ring S-24	10185	82	Retaining ring E-7	10285
34*2	Air controller 'Y'	41222	83	O-ring P-7	10149
35	O-ring P-30	14445	84	Nipple	42479
36	Pan head tapping screw 3×6	29670	85	Plate	41299
37	Mandrel tank	41146	86	O-ring S-10	10151
37U	Mandrel tank unit (with cap)	41149	87	Rotary joint unit	42502

*1 Part no. 14 includes part nos. 13, 15, 16, 19 and 20.
*2 Part no. 34 includes part no. 36.
*3 Part no. 53 includes part nos. 44, 45, 46 and 54.
*4 Part no. 57 includes part nos. 56 and 58.
Parts with circled Index No. are consumable parts. They should be replaced periodically.

ORDERING PARTS

Indicate the tool model, part name, code no. and quantity as shown below when ordering.

Model	Part Name	Code No.	Qty.
AR2000HV(A)	Ultra jaws (pair) 'H'	10493	1
AR2000HV(A)	Frame head 'H'	29709	1

* When parts are modified for improvement, the older parts are kept in stock for a period of five years.